

# BUFFET & CATERING

Frame Riser Assembly



## GASTRONORM CRATE FRAME PRODUCT & ASSEMBLY INSTRUCTIONS

2023



# TWO-TIERED CRATE FRAME RISER

- Perfect for breakfast buffets, grab-and-go stations or merchandising
- Removable chalkboard panel to customize presentation
- Features adjustable shelves so you can display flat or on an angle
- Ships flat. Lock & channel design for quick, easy assembly



Item #	Description	Min Order
<b>BLACK POWDER COATED STEEL</b>		
11000	21½ x 13½ x 22¼	1 ea

Each tier of this riser display is designed to fit:  
(1 ea) Full, (2 ea) Half, (3 ea) Third or (4 ea) Fourth  
Size Wood Crates featured on pages 64–65

## EASY TO BUILD, BUILT TO DISPLAY EASILY.

Shown below without chalkboard sign



11000 Two-Tiered Riser Frame shown with:  
(1 ea) CRATE12 Half Size Crate  
(1 ea) CRATE124 Half Size Crate  
(1 ea) CRATE11 Full Size Crate



11000 Two-Tiered Riser Frame shown with:  
(1 ea) CW60100 Full Size Cooling Plate  
(1 ea) CRATE11W\* Full Size Crate  
\*Food pan not included



11000 Two-Tiered Riser Frame shown with:  
(1 ea) MG1WM Frostone White Marble Tray  
(1 ea) CRATE114BK Full Size Crate\*  
(1 set) 700012 Croffhouse Mixing Bowls  
\*Food pan not included



11000 Two-Tiered Riser Frame shown with:  
(1 ea) CRATE114BK Full Size Crate  
(1 ea) CRATE11BK Full Size Crate\*  
\*Food pan not included




# TIERED CRATE FRAME

## ASSEMBLY INSTRUCTIONS


### COMPONENT LIST




CROSS BAR




LEFT LEG



RIGHT LEG




CHALKBOARD PANEL



TIER FRAME


### STEP 1

Stand the left leg upright. Take the first cross bar and insert the knob on the underside into the key-hole on the top of the leg. Push cross bar backwards to lock in place.




### STEP 2

Stand the right leg upright. Align with the second knob of the cross bar. Insert the cross bar into the key hole of the right leg and push backwards to lock in place.




### STEP 3

Take the second cross bar and align the knobs with the key holes in the legs. Make sure the cross bar is facing in the opposite direction of the first cross bar. Insert the knobs into the key holes, pull forward to lock in place.




### STEP 4

Place the first tier frame on the lower level.




### STEP 5

Place the second tier frame on the upper level.





### STEP 6

Line up the hooks on the chalkboard panel with the holes on the back of the frame. Insert the hooks into the holes and push down on the panel to lock in place.



Each level can be angled by releasing the foot on each tier frame and pushing the foot back as far as it can go.



Ships from Gurnee, IL 60031

World Headquarters: 801 Lakeside Drive, Gurnee, Illinois 60031 | p: 847.855.9000 | f: 847.855.9012 | Customer service: 800.323.8321

info@tablecraft.com | www.tablecraft.com | facebook.com/tablecraft